# MediTrans<sup>®</sup> 30 MediTrans<sup>®</sup> 60

# **Collection Trolley** for 30 and 60 Liter Waste Containers

The **MediTrans** collecting and transporting trolleys allow for a contact-free waste collection and a safe transport of waste generated in medical facilities.

### The advantages:

- No risk of injury and infection for the staff during waste manipulation
- Easy handling, requires little space
- Lid opened with foot-pedal for contact-free waste collection
- Cart does not slip away when the lid is opened – stable stand due to two-leg / two-wheel technology
- Automatic lid closing

   no open waste containers anymore
- Waste container firmly secured on trolley
- Easy to move by tipping the container at the practical handle
- Field-tested design
- Adaptable

to one-way or reusable 30 and 60 liter collection containers

Hygienic

by the use of inserted bags in the reusable containers

 Undercounter model MEDITRANS 30 undercounter option possible by removing the handle.

# The practical aids

## for safe and clean disposal in

- → Hospitals
- → Laboratories
- Dialysis centres
- Doctor's practices etc.





## Proved Technology Tested System Solution Maximum Safety



# MEDITRANS<sup>®</sup> 30 **MEDITRANS**<sup>®</sup>60

**Collecting Trolley for 30 and 60 Liter Waste Containers** 

### The METEKA Waste Collecting System:

The puncture-proof **MEDITAINER**-waste container is filled very easily by simply stepping on the foot pedal of the MEDITRANS transport trolley to open the lid and throw in the waste.

#### Operators have both hands free to handle the waste.

With this method, contaminations on the lid surface as well as germ transfer are impossible. The waste bag inserted in the reusable containers serves only for waste disposal after the disinfection or sterilization process. This ensures hiahest hygiene standards. Filled MEDITAINER containers are transported safely on MEDITRANS transport trolleys with effortless ease.

The optionally offered special MEDITAINER lid is closed by 8 latches. The container is fully closed even if a waste bag is turned over the rim of the container.

Technical data:	MediTrans 30	MediTrans 60
Handle height	930 mm	930 mm
Handle height of undercounter model	590 mm	-
Width	370 mm	370 mm
Depth	540 mm	540 mm
Lid diameter	410 mm	410 mm
Container floor space	330 mm	330 mm
Stainless steel	Standard	Standard
Anti-static light wheels	Standard	Standard



MEDITRANS 30 with 30 liter waste container and detachable handle

#### With best compliments



MEDITRANS 60 with 60 liter waste container



**METEKA** GmbH A-8750 Judenburg, Viktor-Kaplan-Straße 7 Tel. +43 (0)3572 / 85 1 66, Fax +43 (0) 3572 / 85 16 66 e-mail: info@meteka.com, http://www.meteka.com